


Dual Button (Duress and Holdup) Reset Procedure

1. Once the button is pushed you can observe the indicator on the button that it is "Red"



2. Insert the key and turn. It will only move slightly



3. Check to make sure the indicator is now "Green"

